

Endura Astragal Strike and Deadbolt Plates

STRIKE PLATE DEADBOLT PLATE


Replacement Instructions



STEP 1: PREPARE ASTRAGAL FOR NEW PLATES




a. Mark the center line of the plate opening(s) on the edge of the astragal body.



b. Unscrew and discard the old plate(s).


STEP 2: INSTALL NEW PLATES



a. Attach the new plates, ensuring the opening center aligns with the marking from Step 1a.



8817 West Market Street, Colfax, NC 27235 800.334.2006 Fax: 336.668.4478 www.enduraproducts.com



b. Close the active door to ensure latch and deadbolt properly engage. Loosen strike plate screws and adjust place position as necessary for proper engagement. Wipe off pencil mark when complete.

SKU: BD-INST-ASTPLATES Revised: 02.13.2017